





- 1. STRIP CABLE AS SHOWN. DO NOT NICK CENTER CONDUCTOR.
- 2. SOLDER CONTACT TO CENTER CONDUTOR.
- 3. INSERT CABLE INTO BODY UNTILL IT BOTTOMS OUT. SOLDER OUTER CONDUCTOR TO BODY.

ASSEMBLY PROCEDURES

- STANDARD TOLERANCES
 .X ±0.2
 .XX ±0.01
 .XXX ±0.005

*STANDARD TOLERANCES APPLY ONLY TO DIMENSIONS IN INCHES

FAIRVIEW MICROWAVE INC.

ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM

NOTES:
1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.
2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.
3. DIMENSIONS ARE IN INCHES [mm]. CAD FILE DWG NO FMCN1330 080117 SHEET 1 유 1 SCALE N/A CAGE CODE SIZE

⊳

2233

3FKR5