

Notes:

- Warranty void if removed.
 The FMAM4067 includes a
- this design. The baseplate temperature should be monitored and maintained not exceed +50°C. Operation above +50°C baseplate temperature will The FMAM4067 includes a temperature sensor label on the side of the package. A heatsink and optional cooling fan is required for reliable operation of the label is removed the warranty will be voided. likely cause eventual damage to the device. Any elevated temperature level running >50°C will become registered on the temperature sensor label. If

THESE COMMODITIES, TECHNOLOGY OR SOFTWARE WERE EXPORTED FROM THE UNITED STATES IN ACCORDANCE WITH THE EXPORT ADMINISTRATION REGULATIONS. DIVERSION CONTRARY TO U.S. LAW PROHIBITED.

