



## STRIPPING DIMENSIONS 0.059 [1.5]

ASSEMBLY PROCEDURES

## STANDARD TOLERANCES .X ±0.2 .XX ±0.1 .XXX ±0.05

\*STANDARD TOLERANCES APPLY ONLY TO DIMENSIONS IN INCHES

- 1. STRIP CABLE AS SHOWN. DO NOT NICK CENTER CONDUCTOR.
- 2. SLIDE CABLE INTO CONNECTOR INSURING CENTER CONDUCTOR MATES WITH CENTER PIN.
- 3. OUTER CONDUCTOR BOTTOMS OUT WITH BODY SHOULDER. SOLDER OUTER CONDUCTOR TO BODY.

## ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM FAIRVIEW MICROWAVE INC

TITLE

NOTES;
1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.
2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.
3. DIMENSIONS ARE IN INCHES [mm].

DWG NO CAD FILE 083016 FMCN1018 SHEET SCALE CAGE CODE N/A SIZE ⊳ 3FKR5 2233