



TTL 0 = Low Loss State  
 TTL 1 = Isolated State

E1	E2	Signal Path
0	1	J1 - J2
1	0	J1 - J3

# FAIRVIEW MICROWAVE INC.

ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM

NOTES:  
 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.  
 2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.  
 3. DIMENSIONS ARE IN INCHES [mm].

TITLE		DWG NO		CAGE CODE	
		SDS-0102-SPDT-SMA		3FKR5	
CAD FILE	051217	SHEET		SCALE	N/A
				SIZE	A
					2233