

AGANWANI	06/07/22	INITIAL RELEASE	Α
APPROVED	DATE	DESCRIPTION	REV.
		ZEVICIONO	






ASSEMBLY PROCEDURES

- 1. SLIDE CLAMP NUT (1), WASHER (2) & GASKET (3) OVER CABLE. STRIP CABLE AS SHOWN IN ASSEMBLY (A).

 DO NOT CUT DIELECTRIC.
- 2. SLIDE ADAPTER (4) OVER CABLE UNTIL ADAPTER (4) BOTTOMS ON OUTER CONDUCTOR. SOLDER ADAPTER (4) TO OUTER CONDUCTOR USING MINIMUM HEAT.
- 3. STRIP CABLE AS SHOWN IN ASSEMBLY (B).
 SOLDER CONTACT TO CENTER CONDUCTOR.
 SLIDE ASSEMBLY FORWARD & TIGHTEN TO BODY.




MOUNTING HOLE

THESE COMMODITIES, TECHNOLOGY OR SOFTWARE WERE EXPORTED FROM THE UNITED STATES IN ACCORDANCE WITH THE EXPORT ADMINISTRATION REGULATIONS. DIVERSION CONTRARY TO U.S. LAW PROHIBITED.



an INFINIT® brand

TIT IE



THE INFORMATION AND DESIGN IN THIS DOCUMENT IS THE PROPERTY OF RVIEW MICROWAVE CORPORATION.
ALL RIGHTS RESERVED.

N/A